

## DENON

# Compact CD/MP3 Player DN-S 1000

### 3 Hot Points

- 1. Compact & Portable
- 2. Scratch & On-board Effects
- 3. Advanced MP3 Functionality

Introducing the all-new DN-S1000 tabletop CD/MP3 player from Denon DJ.

A small compact feature rich CD/MP3 player carefully designed to fit the requirements of today's DJ's. Whether you're a Mobile DJ, Club DJ, International DJ or just a novice, the DN-S1000 is packed with creativity, performance, experience and reliability.

#### Advanced Features

- MP3 Playback: fully supports,
  - MP3 Seamless Looping w/B Point Trim
  - MP3 Scratching
  - MP3 Hot Starts- MP3 Effects
  - C.B.R & V.B.R. encoding up to 320 kbps
  - ID3 Tags, displays: (Title, Artist, Album)
  - MP3 File Search System (locate your files by name fast and easy)
- Next Track Function w/Cross Fade

Storing hundreds of your favourite mp3's on one disc is great. But what if you want play other files from the same disc back to back? Well, with our world's first Next Track Reserve function, you can search for a song by name and cross fade seamlessly to that file for a smooth non-stop mix.

- \* The crossfade time is user adjustable.
- \*\* Also available for CD audio discs as well.
- 3-Way BPM Counter

AUTO BPM, Manual TAP and Manual BPM BPM value is also possible.

• 4 Built-in Effects

You can activate the Effector function by selecting one of the 4 effects: Flanger, Filter (High-Mid-Low), Echo and worlds first Echo/Loop.

• 3 Platter Effects

Drag-Start, Brake & Reverse effects can be used for MP3 or CD audio discs.

• Fader Start Control terminal (compatible with all Denon DJ mixers)



• Digital Outputs

Constant Digital Output at 44.1 kHz is present when using all functions.

### **Other Features**

- 100 mm long stroke Slider with center click for Playback Speed Control
- Seamless Loop: Two seamless loops are available. (CD or MP3)
- Hot Start

Two Hot Starts (A1 and A2) can be made on the fly and used as a stutter point as well. (CD or MP3)

• Loop End point B Trim/Move

The B point for the seamless loop can be easily adjusted on-thefly using the Scratch Disc.

- CD TEXT support (with scrolling display for long names)
- Power On Play

Unattended playback is possible upon power up. Great for restaurants, bars and nightclubs at opening time.

CD Memo function

Cue point, Playback Pitch, Pitch Range, Pitch ON/OFF, Key Adj ON/OFF, and Seamless Loop A and B data can be stored for later recall..

- Instant Start (0.02sec)
- CD-R/RW Disc Playback

• Pitch Control

\* CD:  $\pm 4\%$  (0.1% step),  $\pm 10\%$  (0.1% step),  $\pm 16\%$  (0.1% step),  $\pm 24\%$  (0.1% step),  $\pm 100\%$  (1.0% step)

\* MP3:  $\pm 4\%$  (0.1% step),  $\pm 10\%$  (0.1% step),  $\pm 16\%$  (0.1% step)

• Pitch Bend

 $\pm 32\%$  (when variable pitch range is  $\pm 4$ , 10, 16 or 24%)

 $\pm 99\%$  (when variable pitch range is  $\pm 100\%$ )

• Key Adjust (=Master Tempo): +100% / -99% max

• EOM (Flashes the status time bar when the track is about to end)

• Shock-Proof Memory: 20 sec (CD), 100sec.(MP3)

• Fluorescent Tube Display with Dot Matrix text support

• Platter Hold: Extreme pitch bend by the Scratch Disc  $\pm 100\%$ 

• Fast Search/Manual Search

• Quick Jump:

We made searching fast & easy. You can now jump around within a track with precise user adjustable increment time steps.

• Search precision: 1/75 sec.

• Software Upgradeable by CD-ROM disc

**Specifications** Frequency Response 20 Hz - 20 kHz **Total Harmonic Distortion** 0.01% 95 dB S/N ratio **Channel Separation** 85 dB Analog outputs (1 kHz, 0 dB playback) Transfer and Connector Unbalanced, RCA connector Output Level 2.0 Vrms, 10 kohm Digital outputs Transfer and connector Coaxial Signal format IEC958, Type II **Dimensions Outer Dimensions:** 226 x 92 (with Feet) x 215 mm

8.89 x 3.62 x 8.46 inch

Weight: 3.0 kg, 6.6 lbs.

Design and specifications are subject to change without notice.

Power Consumption: 15W





1. AUTO CUE: ON\*/OFF

2. NEXT TRACK FADE TIME: OFF/1/2\*/3 sec.

3. SCRATCH STROKE: Short\*/Long

4. SCRATCH DELAY TIME: OFF\*/Delay1/Delay2/Delay3

5. JUMP TIME: 10\*/20/30/60 sec.

6. PITCH RANGE:  $\pm 4/ \pm 10^*/\pm 16/\pm 24$  sec.

7. EOM: OFF/10\*/15/20/30/60/90 sec.

8. TOTAL TIME DISPLAY: ON/OFF\*

9. FADER: PLAY/CUE\*/Play/Pause

10. POWER ON PLAY: ON/OFF\*

11. PITCH: Pitch On\*/Key adj On/Pitch Off

12. SINGLE/CONTINUOUS: SINGLE/CONTINUOUS/SINGLE PLAY LOCK\*

13. ELAPSED/REMAIN: ELAPSED\*/REMAIN

14. MEMO ALL CLEAR: YES/NO\*

15. VERSION DISPLAY

16. PRESET CLEAR: YES/NO\*

\*: Default





